


## ***Digital Voltage Stabilizing Vibratory Feeder Controller***

---



**Instruction Book of SDVC21  
Intelligent Digital Voltage Stabilizing Vibratory Feeder Controller**



## Preface

Thank you for choosing CUH Digital Vibratory Feeder Controllers. (The controller for short in the following text)

This instruction book includes notes for installing, debugging, parameter setting, maintaining and trouble shooting of the controller. Please read this instruction book carefully before operating the controller and keep it properly.

### **This instruction book applies to the following model:**

→ Intelligent Digital Voltage Stabilizing Vibratory Feeder Controller SDVC21

## **Notice :**

- Never hot swap nor touch the contacts in any case to avoid electric shock or other accidents.
- Never connect the controller to 380V AC which may cause unrecoverable damage. (Choose products that are designed for 380V AC when needed)
- Never switch the input of the controller by way of cutting off power supply through a relay or other devices, otherwise service life of the controller may reduced severely.
- The controller is designed to work in a cool and dry environment. Never run outdoors to avoid soaking or sun exposure. Operating the controller within the temperature range that its electrical characteristics demand.
- Never operate the controller under the condition that beyond its designed limits.
- Operate the controller in accordance with this instruction book strictly. We will not assume any civil or criminal liability if the equipment damage or personal injury is caused by incorrect operation.



Never open the controller shell to avoid electric shock. Contact CUH if the controller breaks down.

Never try to revamp the controller since the solid state circuit boards inside the controller can not be repaired, and there's no adjustable part.

# Operating Environment

## Inspections Before Using

Every controller will go through rigorous quality inspection before delivery and is packed with crash-proof packaging.

## Please Check the Following Items After Unpacking:

- Whether the controller is damaged in appearance
- Whether model of the controller are exactly what you ordered

## Runtime Environment

Please follow the notes below to ensure better performance and longer lifetime of the controller

- Well-ventilated environment
- Keep away from water, steam, dust and especially oily dust
- Keep away from corrosive or flammable gas and liquid
- Keep away from flying dust and metal particles
- Firmly fixed to avoid vibration
- Keep away from electromagnetic interference
- Operating within the temperature range of  $-10\text{ }^{\circ}\text{C}$  to  $40\text{ }^{\circ}\text{C}$

# Contents

Chapter I Features	1
Chapter II Installation Guide	2
Chapter III Components Descriptions	5
Chapter IV Function Descriptions	7
4.1 Output Voltage Setting	7
4.2 Output Frequency Setting	8
4.3 Soft Startup Time Setting	9
4.4 Output Switch	9
4.5 Maximum Output Voltage Restriction	10
4.6 Keypad Locking	10
4.7 Default Settings Restoration	11
Chapter V Sensors and Signal Control	12
5.1 Intelligent Photoelectric Sensing	12
5.2 Using Method of the NPN Switch Sensor	15
5.3 Using Method of the 2 <sup>nd</sup> NPN Switch Sensor	18
5.4 Logical Relation Setting of the Control Signal	21
5.5 Controlling Output	22
5.6 Remote Speed Control	25
5.7 Feeding Speed Preset	26
Chapter VI Security Functions	27
6.1 Automatic Voltage Stabilizing	27
6.2 Short-Circuit Protection	27
6.3 Current Overload Protection	27
6.4 Overheat Protection	27
Appendix	
Appendix A: Dimensions	28
Appendix B: Output Interface Definition	29
Appendix C: Signal Interface Definition	29
Appendix D: Function Table	30
Appendix E: Electrical Specification	31
Appendix F: Troubleshooting Tips and Error Indicator Significations Description	32

## Chapter I Features

The controller is specially designed for controlling vibratory feeder in the automation systems. Combined with the latest electronic technology and elaborate design, the controller provides the following convenient and practical features:

**Automatic Voltage Stabilizing:** The controller can eliminate feeding speed variation caused by mains voltage fluctuation.

**Voltage Adjusting:** Output voltage ranges from 0V to 260V.

**Soft Startup:** In order to avoid sudden shock to the work pieces, the controller can gently increase output voltage from 0 to the pre-set value when startup.

**Soft Startup Time Setting:** Soft Startup Time can be set exactly in digital numbers.

**Halt when Work-pieces are full:** A NPN switch sensor can help to halt the controller when work-pieces are full and to fulfill the functions of Soft Startup Time Setting, Startup Delay, Shutdown Delay, and Logical Relation Adjusting.

**Controlling Output:** The Controlling Output signal outgoing from the transistor can coordinate a solenoid or other external devices with the controller.

**Overheat Protection:** The controller will halt its output to protect itself when operation temperature is too high.

**Current Overload Protection:** The controller will halt its output to ensure operating safety of the equipment when operation current exceeds its rated value.

### The Following Features Can be Customized:

**Dual Control Signals Input:** Dual control signals input of Work-pieces-Full and Work-piece-Empty could form the logical control relation of AND, OR, NOT, XOR, and all the others.

**Output Voltage Preset Function:** Up to four preset output voltage values can be chosen by external control signals.

**Intelligent Photoelectric Sensing:** Our adaptive Intelligent Photoelectric Sensor can help to stall the controller when work-pieces are full or work-pieces are empty and to fulfill the functions of Inching Startup Time Setting, Startup Delay, Shutdown Delay, and Logical Relation Adjusting.

**Remote Speed Control:** Output voltage of the controller can be controlled by an external potentiometer, a PLC, or a voltage control signal ranging from 1V to 5V.

**CUH** attaches great importance to the product quality management and safety performance. Apart from the high-quality components we use and rigorous quality control system, **CUH** has taken account of possible accidents users may encounter and provides the following protective functions to maximum the controller's practicability.

**Short-Circuit Protection:** If output of the controller is short-circuited, the controller will halt its output until restarted.

**Current Overload Protection:** The controller will halt its output to ensure equipments' operating safety when operation current exceeds its rated value.

**Overheat Protection:** The controller will halt its output to protect itself when operation temperature is too high.


**CUH** controllers are strictly compliant with CE certification.



## Chapter II Installation Guide

### Step One:

Open the packing box and connect the Output Power Cable to the vibrator's electromagnetic coils.



### Note:

Make sure the vibrator's electromagnetic coils is connected to the two output pins of the Output Power Cable and the electromagnetic coils is reliably grounded otherwise series security incident may occur.

### Step Two:

Connect the Output Power Cable plug to the Output Socket of the controller.




**Step Three:**

Connect the Input Power Cable to the controller and lock the power nut.



**Step Four:**

Connect the plug of the Input Power Cable to the mains jack.



## Chapter III Components Description

There are 6 buttons on the control panel including the **FUNC** button to shift among different functions, the **▲** button to increase the parameter value, the **▼** button to decrease the parameter value, the **Vol+** and **Vol-** buttons to adjust the Output Voltage value and the **ON/OFF** button.

### Keyboard Description


**Output Voltage Indicator:**  
The indicator lights up as the controller enters Output Voltage Adjusting status.

**Output Frequency Indicator:**  
The indicator lights up as the controller enters Output Frequency Adjusting status.

**Startup Delay Indicator:**  
The indicator lights up as the controller enters Startup Delay Time Adjusting status.

**Shutdown Delay Indicator:**  
The indicator lights up as the controller enters Shutdown Delay Time Adjusting status.

**Soft Startup Indicator:**  
The indicator lights up as the controller enters Soft Startup Time Adjusting status.



**Output Voltage Increasing Button & Output Voltage Decreasing Button:**  
Output Voltage can be changed by these two buttons. When the Keypad Locking function is on, these two buttons lose efficacy.

**Advanced Parameter Increasing Button & Advanced Parameter Decreasing Button:**  
Advanced parameters can be adjusted by these two buttons.

**FUNC Button:**  
Shift advanced parameters by pressing this button.

**Soft Power Switch Button:**  
Startup or shutdown output of the controller by pressing this button

## Descriptions of the Status Indicators

**Remote Speed Control Indicator:**  
The indicator lights up when Remote Speed Control signal is available as the Vol+ and Vol- buttons loses efficacy.

**Speed A Indicator:**  
The indicator lights up as the corresponding external control signal is available.

**Speed B Indicator:**  
The indicator lights up as the corresponding external control signal is available.


**Saturation Indicator:**  
The indicator lights up when the preset Output Voltage value exceeds Input Voltage value.

**Stop Indicator:**  
The indicator lights up as Output of the controller is shutdown by the ON/OFF button.

**LED displayer:**  
The LED displayer indicates the adjustable parameter at present.



## I/O Interface Descriptions




# Chapter IV Function Descriptions


## 4.1 Output Voltage Setting

The output voltage can be set directly and digitally through the control panel. Benefit from the unique voltage stabilizing function, output voltage of the controller won't fluctuate as the input voltage does. So that a vibrator can work stably in unstable input voltage environment.

- ▶ Turn on the power switch
- ▶ The Output Voltage Indicator lights up as the controller enters Output Voltage Adjusting status when the LED displays the voltage symbol U and the previously set voltage value.
- ▶ Adjust the Output Voltage value by pressing the **Vol+** or **Vol-** button.




- ▶ Output Voltage value of the controller can not exceed Input Voltage value. If Output Voltage value is set too close to Input Voltage value, the controller fails to stabilize its voltage output and the Saturation Indicator lights up.
- ▶ If Output Voltage value is set too close to zero, the controller fails to stabilize its voltage output and the Saturation Indicator lights up.



## 4.2 Output Frequency Setting

The controller can choose to output frequency at the value of the mains' or the mains' double.

- ▶▶ Press the **FUNC** button and hold for 2 seconds to enter the Basic Parameters Adjusting status.
- ▶▶ Press the **FUNC** button repeatedly until Shifting to the Output Frequency Adjusting status (E) as the Output Frequency Indicator lights up.
- ▶▶ Press the **▲** or **▼** button to adjust the parameter value.



If the mains frequency is at 50 Hz, when the E parameter is adjusted to HALF, Output Frequency of the controller is at 50 HZ, when the E parameter is adjusted to FULL, Output Frequency of the controller is at 100 HZ.

If the mains frequency is at 60 Hz, when the E parameter is adjusted to HALF, Output Frequency of the controller is at 60 HZ, when the E parameter is adjusted to FULL, Output Frequency of the controller is at 120 HZ.


### 4.3 Soft Startup Time Setting

In order to avoid sudden shock to the work pieces, the controller can gently increase Output Voltage from 0 to the pre-set value when startup.

Soft Startup Time (t): The period of time it takes for the controller to gently increase Output Voltage from 0 to the pre-set value when startup.

- ▶▶ Press the **FUNC** button and hold for 2 seconds to enter the Basic Parameters Adjusting status.
- ▶▶ Press the **FUNC** button repeatedly until Shifting to the Soft Startup Time adjusting status (t) as the Soft Startup Indicator lights up.
- ▶▶ Press the **▲** or **▼** button to adjust the parameter value. The parameter unit is second, and the numerical precision is 0.1.

Adjustable Soft Startup Time ranges from 0.0 second to 9.9 seconds.  
Default value of the Soft Startup Time parameter is 1 second.




### 4.4 Output Switch

The soft-touch Output Switch Button on the panel can turn on/off the controller's output quickly and easily.

- ▶▶ Press the **ON/OFF** button to turn on/off the controller's output. The Stop Indicator lights up as output of the controller is turned off.




Due to the soft-touch switch and digital signal control technology, no spark will generate to spoil the contact. As a result, life-span of the controller and the vibrator will be extended greatly.



## 4.5 Maximum Output Voltage Restriction

Maximum Output Voltage of the controller can be set to prevent damage to the vibrator. Remote Speed Control function is affected by this parameter.

- ▶▶ Press the **FUNC** and **▲** buttons simultaneously and hold for 2 seconds to enter the Advanced Parameters Adjusting status.
- ▶▶ Press the **FUNC** button repeatedly until shifting to the Maximum Output Voltage Restriction status (h).
- ▶▶ Press the **▲** or **▼** button to adjust the parameter value.




Default value of the Maximum Output Voltage is 260V

## 4.6 Keypad Locking

- ▶▶ Press the **ON/OFF** button and hold for 2 seconds to lock all buttons on the panel as the LED displays **⊞**
- ▶▶ Press the **ON/OFF** button and hold for 2 seconds in the locking mode to unlock the keypad.

The **ON/OFF** button will not be affected by the Keypad Locking function.







## 4.7 Default Settings Restoration

This function allows the operator to restore all default parameter settings.

Due to the abundant functions of the controller, many parameters can be adjusted. In order to avoid the circumstance that after too many times modification by a beginner, the controller can not work properly, this function allows the operator to restore default settings to the controller in an easy way.

- ▶▶ Press the **FUNC** and **▲** buttons simultaneously and hold for 2 seconds to enter the Advanced Parameters Adjusting status.
- ▶▶ Press the **FUNC** button repeatedly until 0000 is flashing on the LED display, and then press the **▲** button and hold until ---- is displayed which means default settings have been restored.
- ▶▶ After releasing the **▲** button, the controller enters Output Voltage Adjusting status (U). By this time, all parameters have been restored to default values.



# Chapter V Sensors and Signal Control

The controller can be controlled by many kinds of external signals and sensors. This chapter mainly elaborates using method of the Intelligent Photoelectric Sensor, the NPN Switch Sensors and the PLC.


## 5.1 Intelligent Photoelectric Sensing

Combined with the SDVC-S1 Photoelectric Sensor the function of Intelligent Photoelectric Sensing can be achieved. The SDVC-S1 sensor can filter the interference of background light impacting on the sensitivity of the controller. As a result, the controller can work reliably without manual sensitivity adjustment.

### 5.1.1 Connection Method of the SDVC-S1 Intelligent Photoelectric Sensor


#### Step One:

Open the upper cover plate of the controller.



#### Step Two:

Connect the SDVC-S1 sensor to the terminals of the controller according to the diagram



*Notice:*  
Default logical relation of the sensor is set as work-pieces are empty


### 5.1.2 Startup Delay Time and Shutdown Delay Time Adjusting of the Intelligent Photoelectric Sensor

In most actual applications, the output of the controller should be delayed for a period of time when Startup or Shutdown of the controller is controlled by external signals. Startup Delay Time and Shutdown Delay Time Adjusting function made this kind of application possible. Furthermore, shocks to the work pieces as the controller starts up can be eliminated by adjusting Soft Startup Time.

**Startup Delay (J):** The period of time the controller goes through from receiving a startup control signal to outputting.

- ▶ Press the **FUNC** button and hold for 2 seconds to enter the Basic Parameters Adjusting status.
- ▶ Press the **FUNC** button repeatedly until shifting to the Startup Delay Time Adjusting status (J) as the Startup Delay Time Indicator on the panel lights up.
- ▶ Adjust the parameter by pressing the ▲ or ▼ button. The parameter unit is second, and the numerical precision is 0.1.


*Adjustable range of the parameter is from 0.0 to 9.9 seconds  
Default value of the parameter is 0.2 seconds*



**Shutdown Delay (L):** The period of time the controller goes through from receiving a shutdown control signal to cutting off output.


- ▶ Press the **FUNC** button and hold for 2 seconds to enter the Basic Parameters Adjusting status.
- ▶ Press the **FUNC** button repeatedly until shifting to the Shutdown Delay Time Adjusting status (L) as the Shutdown Delay Time Indicator on the panel lights up.
- ▶ Adjust the parameter by pressing the ▲ or ▼ button. The parameter unit is second, and the numerical precision is 0.1.

*Adjustable range of the parameter is from 0.0 to 9.9 seconds  
Default value of the parameter is 0.2 seconds*



### 5.1.3 Logical Relation Adjusting of the Intelligent Photoelectric Sensor

Under normal circumstances, the receiving end of the Intelligent Photoelectric Sensor receives no optical signal, and the controller runs by default. But in some special applications the controller needs to be stopped when the receiving end receives no optical signal. Adjusting this parameter can fulfill these kind of applications.





- ▶▶ Press the **FUNC** and **▲** button simultaneously and hold for 2 seconds to enter the Advanced Parameters Adjusting status.
- ▶▶ Press the **FUNC** button repeatedly until Shifting to the Logical Relation Adjusting status of the Intelligent Photoelectric Sensor.
- ▶▶ Adjust the parameter by pressing the **▲**



- When Logical Relation is set as Normal Open, namely no optical signal received, the controller runs.
- When Logical Relation is set as Normal Close, namely no optical signal received, the controller stops.

The parameter is set as Normal Open by default



## 5.2 Using Method of the NPN Switch Sensor

The controller can operate with many kinds of sensors such as switch sensors, optical switch sensors and fiber optic sensors.

### 5.2.1 Connection method of the NPN Switch Sensor

#### Step One:

Open the upper cover plate of the controller.


#### Step Two:

Connect the NPN Proximity Switch Sensor to the terminals of the controller according to the diagram.




Ground Wire ----- D1  
Signal Wire ----- D2  
+24V Output ----- D3

Ground Wire  
Signal Wire  
+24V Output



#### Convention

The blue wire represents ground wire  
The black wire represents signal wire  
The brown wire represents power wire.



## 5.2.2 Startup Delay Time and Shutdown Delay Time Settings of the NPN Switch Sensor

By default, Intelligent Photoelectric Sensor and Switch Sensor share the same Startup Delay Time and Shutdown Delay Time. Operators can also set Startup Delay Time and Shutdown Delay Time of the NPN Switch Sensor independently.


**Startup Delay (J-):** The period of time the controller goes through from receiving a startup control signal to outputting.

- ▶▶ Press the **FUNC** and **▲** buttons simultaneously and hold for 2 seconds to enter the Advanced Parameters Adjusting status.
- ▶▶ Press the **FUNC** button repeatedly until shifting to the Startup Delay Time Adjusting status ( J----- ).
- ▶▶ Adjust the parameter by pressing the **▲** or **▼** button. The parameter unit is second, and the numerical precision is 0.1.

*Adjustable range of the parameter is from 0.0 to 9.9 seconds*

*Default value of the parameter is*

*The independent Startup Delay of the NPN Switch Sensor will be closed when the parameter value is adjusted to 0*




**Shutdown Delay (L-):** The period of time the controller goes through from receiving a shutdown control signal to cutting off output.

- ▶▶ Press the **FUNC** and **▲** buttons and hold for 2 seconds to enter the Advanced Parameters Adjusting status
- ▶▶ Press the **FUNC** button repeatedly until shifting to the Shutdown Delay Time Adjusting status ( L----- ).
- ▶▶ Adjust the parameter by pressing the **▲** or **▼** button. The parameter unit is second, and the numerical precision is 0.1.

*Adjustable range of the parameter is from 0.0 to 9.9 seconds*

*Default value of the parameter is L---*


*The independent Shutdown Delay of the NPN Switch Sensor will be closed when the parameter value is adjusted to 0*



- ➔ When J- and L- values are adjusted to 0, Startup Delay Time and Shutdown Delay Time of the Switch Sensor will be the same with Startup Delay Time and Shutdown Delay Time of the Intelligent Photoelectric Sensor.
- ➔ Startup Delay Time and Shutdown Delay Time of the Intelligent Photoelectric Sensor will not be affected by the parameter of J- or L-.

### 5.2.3 Logical relation setting of the NPN Switch Sensor (Halt when work-pieces are full)

Under normal circumstances, the controller receives no signal from the NPN Switch Sensor and runs by default. But in some special applications the controller needs to be stopped when receives no signal from the NPN Switch Sensor. Adjusting this parameter can fulfill these kind of applications.





- ▶▶ Press the **FUNC** and **▲** buttons and hold for 2 seconds to enter the Advanced Parameters Adjusting status.
- ▶▶ Press the **FUNC** button repeatedly until Shifting to the Logical Relation Adjusting status of the NPN Switch Sensor ( $\Gamma 2$ ).
- ▶▶ Adjust the parameter by pressing the **▲** or **▼** button.



- When Logical Relation is set as Normal Open, namely no signal received, the controller runs
- When Logical Relation is set as Normal Close, namely no signal received, the controller stops.

*The parameter is set as Normal Open by default*



### 5.3 Using Method of the 2<sup>nd</sup> NPN Switch Sensor

The controller allows three sensors connecting to it, one Intelligent Photoelectric Sensor and two NPN Switch Sensors. The functions of Halt when work-pieces are full and Halt when work-pieces are empty can work with the help of these sensors .




#### 5.3.1 Connection method of the 2<sup>nd</sup> NPN Switch Sensor

##### Step One:

Open the upper cover plate of the controller.

##### Step Two:

Connect the 2<sup>nd</sup> NPN Proximity Switch Sensor to the terminals of the controller according to the diagram.



##### Commonly

The blue wire represents ground wire  
 The black wire represents signal wire  
 The brown wire represents power wire



### 5.3.2 Startup Delay Time and Shutdown Delay Time Settings of the 2<sup>nd</sup> NPN Switch Sensor

By default, Intelligent Photoelectric Sensor and the two NPN Switch Sensor share the same Startup Delay Time and Shutdown Delay Time. Operators can also set Startup Delay Time and Shutdown Delay Time independently for the 2<sup>nd</sup> NPN Switch Sensor.


**Startup Delay (J \_):** The period of time the controller goes through from receiving a startup control signal to outputting.

- ▶ Press the **FUNC** and **▲** buttons simultaneously and hold for 2 seconds to enter the Advanced Parameters Adjusting status.
- ▶ Press the **FUNC** button repeatedly until shifting to the Startup Delay Time Adjusting status (J \_ ---)
- ▶ Adjust the parameter by pressing the **▲** or **▼** button. The parameter unit is second, and the numerical precision is 0.1.

*Adjustable range of the parameter is from 0.0 to 9.9 seconds*

*Default value of the parameter is J \_---*

*The independent Startup Delay of the 2<sup>nd</sup> NPN Switch Sensor will be closed when the parameter value is adjusted to 0*




**Shutdown Delay (L \_):** The period of time the controller goes through from receiving a shutdown control signal to cutting off output.

- ▶ Press the **FUNC** and **▲** buttons simultaneously and hold for 2 seconds to enter the Advanced Parameters Adjusting status.
- ▶ Press the **FUNC** button repeatedly until shifting to the Shutdown Delay Time Adjusting status (L \_ ---).
- ▶ Adjust the parameter by pressing the **▲** or **▼** button. The parameter unit is second, and the numerical precision is 0.1.

*Adjustable range of the parameter is from 0.0 to 9.9 seconds*

*Default value of the parameter is L \_---*

*The independent Shutdown Delay of the 2<sup>nd</sup> NPN Switch Sensor will be closed when the parameter value is adjusted to 0*




→ When J \_ and L - values are adjusted to 0, Startup Delay Time and Shutdown Delay Time of the 2<sup>nd</sup> Switch Sensor will be the same with Startup Delay Time and Shutdown Delay Time of the Intelligent Photoelectric Sensor.

→ Startup Delay Time and Shutdown Delay Time of the Intelligent Photoelectric Sensor will not be affected by the parameter of J \_ or L -.

### 5.3.3 Logical Relation Setting of the 2<sup>nd</sup> NPN Switch Sensor (Halt when work-pieces are full)

Under normal circumstances, the controller receives no signal from the 2<sup>nd</sup> NPN Switch Sensor and runs by default. But in some special applications the controller needs to be stopped when receives no signal from the 2<sup>nd</sup> NPN Switch Sensor. Adjusting this parameter can fulfill these kind of application.



- ▶▶ Press the **FUNC** and **▲** buttons simultaneously and hold for 2 seconds to enter the Advanced Parameters Adjusting status.
- ▶▶ Press the **FUNC** button repeatedly until shifting to the Logical Relation Adjusting status of the 2<sup>nd</sup> NPN Switch Sensor (Γ4)
- ▶▶ Adjust the parameter by pressing the **▲** or **▼** button.




- When Logical Relation is set as Normal Open, namely no signal received, the controller runs.
- When Logical Relation is set as Normal Close, namely no signal received, the controller stops.

The parameter is set as Normal Open by default


Γ4 - represents Logical Relation of the 2<sup>nd</sup> NPN Switch Sensor

Normal Open



Γ4 - represents Logical Relation of the 2<sup>nd</sup> NPN Switch Sensor

Normal Close



## 5.4 Logical Relation Setting of the Control Signal



The controller can set the logical relation of the Intelligent Photoelectric Sensor and the Switch Sensor when they work simultaneously.

- ▶▶ Press the **FUNC** and ▲ buttons simultaneously and hold for 2 seconds to enter the Advanced Parameters Adjusting status.
- ▶▶ Press the **FUNC** button repeatedly until shifting to the Logical Relation Adjusting status of the Control Signal (II).
- ▶▶ Adjust the parameter by pressing the ▲ or ▼ button.



- Logical relation AND: The controller runs only when both the Intelligent Photoelectric Sensor and the NPN switch Sensor ask the controller to.
- Logical relation OR: The controller runs when the Intelligent Photoelectric Sensor or the NPN Switch Sensor asks the controller to.
- Logical relation XOR: The controller runs only when the Intelligent Photoelectric Sensor and NPN Switch Sensor output the opposite control signal

Logical relation of the parameter is set as AND by default.



## 5.5 Controlling Output

The controller can output low-voltage controlling signal to cooperate with other devices such as a solenoid valve, a PLC or an electrical relay.

### 5.5.1 Connection Method of the Controlling Output




#### Connection method of the controlled PLC

##### Step One:

Open the upper cover plate of the controller.

##### Step Two:


Connect signal wire and ground wire of the controller to the terminals of the controller according to the diagram.




Relay output or NPN output of the PLC is compatible with the controller.

*Parameter setting methods are the same with that of the switch sensor*

### 5.5.2 Connection Method of the Controlled Solenoid Valve




### 5.5.3 Connection Method of the Electrical Relay




### 5.5.4 Logical Relation Setting of the Controlling Output

- ▶▶ Press the **FUNC** and **▲** buttons simultaneously and hold for 2 seconds to enter the Advanced Parameters Adjusting status.
- ▶▶ Press the **FUNC** button repeatedly until shifting to the Logical Relation Adjusting status of the Controlling Output ( $\Gamma 3$ ).
- ▶▶ Adjust the parameter by pressing the **▲** or **▼** button.



$\Gamma 3$  represents Logical Relation of the Controlling Output


Normal Open



- When Logical Relation is set as Normal Open, the Controlling Output works as the controller runs.
- When Logical Relation is set as Normal Close, the Controlling Output doesn't work as the controller runs.

$\Gamma 3$  represents Logical Relation of the Controlling Output

Normal Close




## 5.6 Remote Speed Control

The function of Remote Speed Control allows the operator to control the Output Voltage by an external potentiometer or a control signal ranging from 1V to 5V. Thus, external remote speed control can be easily achieved by a PLC, a DCS or some other devices.


Remote Speed Control function becomes effective to the controller when the controlling signal exceeds 0.5V. Meanwhile, Remote Speed Control Indicator on the panel lights up and the (Vol+) and (Vol-) buttons lose effectiveness. The LED display shows current Output Voltage if the controller is running in the Output Voltage Adjusting status.

There are linear relationship between 1~5 V controlling voltage and 0~260V Output Voltage

### Connection method of the external potentiometer




### Connection method of the PLC



## 5.7 Preset Speed Switch


The function of Preset Speed Switch can choose the preset speed by means of external control signals, such as a PLC, a PC, sensors or other signal sources to build up a multi-speed feeding control system.

The controller supports two remote speed control switch. The Speed A switch and the Speed B switch are both Low Level effective.



Each speed control switch has a corresponding indicator on the panel. When the controller receives an effective signal, the corresponding indicator will light up.

The two indicators indicate 4 statuses. (A lights up and B goes out, A goes out and B lights up, both light up, both go out). The diagram to the right shows the status that both speed control switches are given effective signals.



By means of speed control switches, the controller shifts to the corresponding speed. The output voltage corresponding to the speed can be adjusted by pressing **Vol+** or **Vol-** button. And the adjusted voltage will be stored automatically. As soon as the speed control signal is received, the controller outputs the corresponding voltage immediately.



## **Chapter VI Security Functions**

### **6.1 Automatic Digital Voltage Stabilizing**

The internal digital voltage stabilizing function of the controller can stabilize feeding speed regardless of mains voltage fluctuation.

### **6.2 Short-Circuit Protection**

If output is short-circuited, the controller will halt its output and display Err01 until restarting the controller.


### **6.3 Current Overload Protection**

The controller will halt its output if output current exceeds rated current caused by faulty operation and display Err02 to protect the controller and customer equipments.


### **6.4 Overheat Protection**

The controller will halt its output if operation temperature exceeds 65°C and display Err03 to protect the controller until operation temperature drops to 60°C.

## Appendix A: Dimensions (mm)



## Appendix B: Output Interface Definition




### Notice:

**A:** Make sure the electromagnetic coils of the vibrator is connected to the two output pins of the Output Power Cable socket and the shell of the vibrator is reliably grounded, otherwise series security incident may occur.

**B:** After welding, make sure the blank area is enshathed by insulating tape or heat-shrinkable tube before insert it into the Output Power Cable socket to avoid electrical leakage or short-circuit.

## Appendix C: Signal Interface Definition



## Appendix D: LED Displayed Characters Definition






Displayed Character	Definition
U 8888	Output Voltage
F 8888	Output Frequency
E 8888	Soft Startup
J 8888	Startup Delay Time of the Intelligent Photoelectric Sensor
J - - - -	Startup Delay Time of the NPN Switch Sensor
J 2 - - -	Startup Delay Time of the 2 <sup>nd</sup> NPN Switch Sensor
L 8888	Shutdown Delay Time of the Intelligent Photoelectric Sensor
L - - - -	Shutdown Delay Time of the NPN Switch Sensor
L 2 - - -	Shutdown Delay Time of the 2 <sup>nd</sup> NPN Switch Sensor
F 1 8888	Logical Relation of the Intelligent Photoelectric Sensor
F 2 8888	Logical Relation of the NPN Switch Sensor
F 3 8888	Logical Relation of the Controlling Output
F 4 8888	Logical Relation of the 2 <sup>nd</sup> NPN Switch Sensor
H 88888	Maximum Output Voltage
N 88888	Logical relation of the Control Signal
00000	Default Settings Restore
- - - - -	Default Settings Restore Successful
E r r o r	Error Information

## Appendix E: Electrical Specification

Item	Value		Unit	Description
	MIN	MAX		
Input voltage	85	260	V	AC RMS Value
Output voltage	0	260	V	Less than Input Voltage
Output Current	-	5	A	SDVC21
Output Frequency	50/100		Hz	the mains frequency is at 50 Hz
	60/120		Hz	the mains frequency is at 60 Hz
Output Power	-	1100	VA	SDVC21
Output Waveform	Tangent Sine			
Voltage Adjusting Accuracy	1		V	
Time Delay Range	0	20	s	
Time Delay Accuracy	0.1	-	s	
Soft Startup Time	0	10.0	VA	
Auxiliary Power Supply Voltage	22	26	V	
Auxiliary Power Supply Current	-	200	mA	
Stand-by Power Consumption	1.5	3	W	
Display Method	-	5	Bit	LED Digital Tube
Voltage Control Method	20		V	Remote Controlled Voltage
	Standard TTL Electric Level			Switching Signal
	6 Buttons plus LED			Touch Button Keyboard
Working Environment Temperature	-10	45	°C	
Operating Environment Humidity	10	85	%	

## Appendix F: Trouble Shooting Tips and Error Explanations

The following tips can help to solve the problems you may encounter

1	No display after power on	<ul style="list-style-type: none"> <li>→ Make sure the power outlet is live</li> <li>→ Make sure the Input Power Cable is reliably connected to the power outlet</li> </ul>
2	Displays normally, but no output	<ul style="list-style-type: none"> <li>→ Make sure the Input Power Cable and Output Power Cable are firmly connected</li> <li>→ Make sure the Output Voltage parameter value is not too small</li> <li>→ Make sure the controller is not stopped by the control signal</li> <li>→ Make sure the controller is not stopped by the parameters that are set as normal off</li> </ul>
3	Control signal loses effectiveness	<ul style="list-style-type: none"> <li>→ Make sure the control signal is correctly inputted</li> <li>→ Make sure the ground wire of the control signal is correctly connected to the controller</li> <li>→ Make sure the Logical Relation of the control signal is set correctly as you expectation</li> </ul>
4	Beat phenomena	<ul style="list-style-type: none"> <li>→ Avoid vibration coupling among the vibrators</li> <li>→ Heighten the resonant frequency of the vibrators</li> </ul>
5	Displays normally, no output, but sound can be heard	<ul style="list-style-type: none"> <li>→ Adjust all parameters as this book instructed</li> </ul>
6		<ul style="list-style-type: none"> <li>→ Output in short-circuit, Make sure the Output Power Cable and the coil are not shorted out</li> </ul>
7		<ul style="list-style-type: none"> <li>→ Output Over Current, Reduce the Output Voltage value and make sure the armature gap is not too big</li> </ul>
8		<ul style="list-style-type: none"> <li>→ Overheat, Place the controller in well ventilated environment</li> </ul>
9		<ul style="list-style-type: none"> <li>→ Reserved, please contact CUH</li> </ul>
10		<ul style="list-style-type: none"> <li>→ Reserved, please contact CUH</li> </ul>



